

Finfloor

Installing **laminated flooring** in
kitchens and bathrooms

Installing laminate flooring in kitchens and bathrooms

Finfloor Durable and Finfloor Original floors are suitable for installation in bathrooms and kitchens.
Finfloor Exitus floors are not suitable for installation in bathrooms and kitchens.

Products with Durable Technology only require to use the perimeter application silicone. It is mandatory to use the expansion profile in the bathroom door (Finfloor with and without DurableTechnology).

To install Finfloor Original in bathrooms and kitchens, you need to use a joint sealant and the perimeter application silicone if you do not, the terms of the warranty will be invalidated. We must always install an expansion profile on the access door to the bathroom.

JOINT SEALANT

Joint sealant for laminate flooring. Stops water filtering between boards. Stops joints lifting. Permits the installation of laminate flooring in wet areas (kitchens and bathrooms), ensuring a long life for the floor.

DIRECTION FOR USE

1. The sub-floor must be clean, dry and free of dust and grease.
2. Before assembling the boards, apply a continuous line along the length and width of the tongue edges of each board.
3. Join the two boards immediately. For a correct seal, the product should overflow from the joint.
4. Leave to dry for 15 to 30 minutes and then remove the excess product using a putty knife.

JOINT FILLER SILICONE

Neutral filler silicone designed to prevent water filtering under floating floors in kitchens and bathrooms. Ideal for filling the expansion gaps between the floating flooring and walls, furniture and bathroom fittings. The high degree of elasticity permits the flooring to expand without losing firmness. Good adherence on building materials, such as concrete, cement, brick, natural stone, metals, wood, fibre glass, PVC and glass.

DIRECTIONS FOR USE:

1. Surfaces must be clean and dry.
 2. Apply with a sealant gun between +5°C and +40°C.
 3. Apply a generous line of product on the expansion gap between the floating floor and the wall, toilet, pipe, etc. until the gap is completely filled.
- Make sure there are no spaces between the wall or the floor and the filling. If the filler/sealant overflows slightly on the floor, it will be hidden later by the skirting board.
4. Smooth with a putty knife or a wet, soapy finger.
 5. Drying 3mm/24h.



✓	Recomendado Recommended Recommandé Empfohlen	Rekomendowane Recomendado Aanbevolen Raccamandato		Anula validez Garantía Invalidates warranty Annule la garantie Garantieausschluss Anuluje ważność gwarancja	Anula validade da garantia Dan vervalt de garantie Annulla la validita' della garanzia
✗	¡No haga esto! Don't do this! Non! Nicht machen!	Nie rób tego Não faça isto! Dit niet doen! Non fare questo!		Amplia información Open information Agrandissez l'info Information erweitern	Szersza Informacja Ampla informação Uitgebreide informatie Maggiori informazioni
	¡Atención, importante! Attention, important! Attention Important Achtung, Wichtig!	Uwaga, Ważne Atenção, Importante! Attention, belangrijk! Importante, Attenzione!			

Finfloor